



Epson TM-U220 and TM-U230 printer driver selection and setup

1. Use correct cable – we were using wrong cables and we gave them to our clients

	Serial cable for serial printer
	Parallel cable for parallel printer

2. Correct drivers and installation steps:

Use of the Epson Advanced printer driver version 4 is required.

Click here to download the version 4 driver: http://www.posdl.com/APD_406aE.exe
(Available at A&A SharedByAll folder) This driver works for all connections (USB, parallel and serial)

Printer Driver Installation

1. Double-click the downloaded file to run the installer
2. Accept the license agreement and click Next
3. Choose Standard Setup and click Next
4. In the Printer Configuration window click the Add button to select the printer to install
5. Select Epson (TM-U220 or TM-U230) Receipt
6. Select the Port Type
For **parallel port**: Select Create a Parallel Port, then select the port from the list of ports.
For **serial port**: Click Create a Serial Port
Select COM: port
Baud rate - Set to 9600
Data Bits - 8
Stop Bits - 1
Flow Control - DTR/DSR
Parity - None
For **Ethernet port**: Select Create Ethernet Port and enter the IP address of the printer.
7. Click Next.
8. Review settings and click next.
9. Driver installation will be complete.